

Configuration of Core Switch for Company Leased Line



Overview

What is a Core Switch? A core switch is the primary switch installed at the backbone of a layered or hierarchical network.

Key Takeaways

A core switch for a leased line network should be configured with management access, VLANs, trunking, inter-VLAN routing, and security to ensure reliable connectivity between branches and the ISP.

Initial Setup and Management
Begin by performing the basic switch setup: rack-mount the switch, connect power and uplink interfaces, and assign a management IP address on a dedicated management VLAN (avoid using VLAN 1) for secure access (). Configure a hostname to identify the switch in the network and set up local user accounts with encrypted passwords. Disable unencrypted protocols like HTTP and Telnet, and enable SSH and HTTPS for secure management ().

VLAN and Interface Configuration

Define VLANs for different departments or services. Assign access ports to the appropriate VLANs and configure trunk ports on uplinks to carry multiple VLANs between the core switch and distribution/access switches (). For each VLAN, configure a Switched VLAN Interface (SVI) to enable Layer 3 routing between VLANs if required ().

Leased Line Integration

Connect the leased line to the core switch via the router interface. Ensure the router at each branch is configured to handle the leased line, providing a point-to-point connection between offices (). The core switch should support static routes or dynamic routing protocols (e.g., OSPF or EIGRP) to direct traffic between the leased line and internal VLANs ().

High Availability and Security

Enable spanning tree protocol (STP) to prevent loops and configure link aggregation on uplinks for redundancy and higher bandwidth (). Implement DHCP on the core switch if it serves as the DHCP server for internal users, and enable DHCP snooping on access switches to prevent rogue DHCP servers (). Optionally, configure IP Source Guard (IPSG) to prevent IP spoofing.

Monitoring and Management

Enable SNMP for network monitoring and management. Verify configurations using commands like show running-config, show vlan brief, and show ip route to ensure VLANs, SVIs, and routing are correctly applied (). Regularly back up the configuration to prevent data loss. By following these steps, the core switch will provide secure, reliable, and efficient connectivity for a company's leased line network, supporting inter-branch communication and internet access through the ISP.

Article Content

Configuration of Core Switch for Leased Line Access

What is a Core Switch? A core switch is the primary switch installed at the backbone of a layered or hierarchical network. These data

VLAN Configuration for Core Switches

The document outlines the configuration for a core switch (Sw-Core) and several access switches (Sw-HR, Sw-Acc, Sw-HelpDesk,

SME Network Solution Typical Configuration Examples

"Gateway + Core Switch + Aggregation Switch + Access Switch + WAC + AP + AR180" Networking: Local Entire Network

Leased Line Configuration Guide

What are the critical steps in commissioning a leased line, and how do these ensure reliable network connectivity? Commissioning

Support

Configure the devices to meet the following requirements: · Configure the spanning tree feature on all the switches to prevent loops. ·

IP Addressing Configuration Guide, Cisco IOS XE 17.x

Configuring the Cisco IOS XE DHCP Server Cisco routers running Cisco IOS XE software include Dynamic Host Configuration

Configuration of Core Switch for Leased Line Access

Unlike access switches, which connect directly to end-user devices, the core switch focuses on aggregating and routing traffic

How to configure Cisco switch in 11 steps?

By configuring your Cisco switch, you can effectively manage its functionality, ensuring versatility, power, and optimal performance.

Internet Leased Line Installation Process Explained

Ending note Installing an internet leased line service is a meticulous process involving multiple stages, from assessing

Configure a Server Core installation of Windows Server and Azure

In Windows Server and Azure Local, you can use the Server Configuration tool (SConfig) to configure and manage

Jio leased line configuration in switch

Learn how to configure Jio leased line in a switch with this informative video

Cisco Router and Switch Configuration Step by Step

Welcome to our detailed step-by-step guide on how to configure Cisco routers and FS Community

We would like to show you a description here but the site won't allow us.

How to Configure a Cisco Switch in 10 Steps

This guide will walk you through the essential tasks needed to configure a Cisco switch, from initial setup to more

The Leased Line Installation Process | Setup & Duration

Leased line installation process Installing leased line business broadband is a multi-step process that requires coordination and

Creating a Base Configuration for a Cisco IOS Switch: A Step-by-Step

Learn how to set up a base configuration for network switches. Secure, optimize, and enable remote access with our step-by-step

Core Configuration of a Router and a Switch in Cisco Packet Tracer ...

Berg IT Training - In this CCST and CCNA introductory-level video, I perform a line-by-line Core Switch and Access Switch configuration

HI TEAM, I have a 2 3850 core switch which is on HA and 2960x for my access switch, i required help on 2 things. 1)

Cisco Switch Layer2 Layer3 Design and Configuration

Layer2 and Layer3 switches are the foundation of any network. After all, any network devices (routers, firewalls, computers, servers

How to Configure Cisco Switches: A Step-by-step Guide

This post is a step-by-step guide including commands, on how to configure a Cisco Catalyst Switch. Learn everything

Leased Line (P2P)

In a line configuration in a computer network, a managed leased line will provide

Planning a Leased-Line Link

When your company rents a leased-line link from a network provider, you typically configure only the system at your end of the link.

What are Leased Lines? A buyers guide to Leased Line ...

Setting up a leased line can involve longer lead times than broadband due to the complexities associated with

How to Configure Cisco Switches: Secure, Scalable, and Reliable ...

Step-by-step guide to configure Cisco switches securely for enterprise networks, covering basic setup, VLANs, AAA, SSH, and best

The Ultimate Guide to Leased Lines for Business

Pretty much every business now needs an internet connection. But it's a different process from simply purchasing a package and

IP Addressing Configuration Guide, Cisco IOS XE 17.x

Configuring the Cisco IOS XE DHCP Server Cisco routers running Cisco IOS XE software include Dynamic Host Configuration

Configuration of Core Switch for Leased Line Access

Unlike access switches, which connect directly to end-user devices, the core switch focuses on aggregating and routing traffic

How to configure Cisco switch in 11 steps?

By configuring your Cisco switch, you can effectively manage its functionality, ensuring versatility, power, and optimal performance.

Internet Leased Line Installation Process Explained

Ending note Installing an internet leased line service is a meticulous process involving multiple stages, from assessing

Configure a Server Core installation of Windows Server and Azure

In Windows Server and Azure Local, you can use the Server Configuration tool (SConfig) to configure and manage

Jio leased line configuration in switch

Learn how to configure Jio leased line in a switch with this informative video

Configuration of Core Switch for Leased Line Access

What is a Core Switch? A core switch is the primary switch installed at the backbone of a layered or hierarchical network. These data

VLAN Configuration for Core Switches

The document outlines the configuration for a core switch (Sw-Core) and several access switches (Sw-HR, Sw-Acc, Sw-HelpDesk,

SME Network Solution Typical Configuration Examples

"Gateway + Core Switch + Aggregation Switch + Access Switch + WAC + AP + AR180" Networking: Local Entire Network

Configuration of Core Switch for Leased Line Access

What is a Core Switch? A core switch is the primary switch installed at the backbone of a layered or hierarchical network. These data

VLAN Configuration for Core Switches

The document outlines the configuration for a core switch (Sw-Core) and several access switches (Sw-HR, Sw-Acc, Sw-HelpDesk,

SME Network Solution Typical Configuration Examples

"Gateway + Core Switch + Aggregation Switch + Access Switch + WAC + AP + AR180" Networking: Local Entire Network

Leased Line Configuration Guide

What are the critical steps in commissioning a leased line, and how do these ensure reliable network connectivity? Commissioning

Support

Configure the devices to meet the following requirements: · Configure the spanning tree feature on all the switches to prevent loops. ·

Related Video Reference

This video was associated with the source search result. Verify technical details against current product documentation and project requirements.

Contact Us

Continue your research online:

Website: <https://rivomultitrade.co.za>

Technical inquiry: <https://rivomultitrade.co.za/contact.html>

This document is for preliminary research. Verify specifications against current standards, product documentation and project requirements.

