

Configuration of a Layer 3 Dual-Core Switch



Overview

This video was associated with the source search result. Verify technical details against current product documentation and project requirements.

Key Takeaways

A Layer 3 dual-core switch can be configured using SVIs for inter-VLAN routing, routed ports for point-to-point links, and enabling IP routing to forward traffic between VLANs and external networks.

Step 1: Enable Layer 3 Routing

Before configuring interfaces, ensure the switch is operating in Layer 3 mode. On Cisco switches, this is typically done with the global configuration command `ip routing` to enable IPv4 routing. For Meraki switches, navigate to Switching > Configure > Routing & DHCP and initialize Layer 3 routing.

Step 2: Create VLANs

Define the VLANs that will segment your network. For example:

```
vlan 10 name Data  
vlan 20 name Voice  
vlan 30 name Management
```

Verify VLAN creation using `show vlan brief`.

Step 3: Configure Switched Virtual Interfaces (SVIs)

SVIs act as Layer 3 gateways for each VLAN. Assign an IP address to each SVI:

```
interface vlan 10 ip address 192.168.10.1 255.255.255.0 no shutdown
interface vlan 20 ip address 192.168.20.1 255.255.255.0 no shutdown
interface vlan 30 ip address 192.168.30.1 255.255.255.0 no shutdown
```

Each SVI should be in a unique subnet, and the line protocol must be up for routing to function .

Step 4: Configure Access and Trunk Ports

Assign access ports to VLANs for end devices:

```
interface fastEthernet 0/1 switchport mode access switchport access vlan 10
interface fastEthernet 0/2 switchport mode access switchport access vlan 20
```

Configure uplink ports as trunks to carry multiple VLANs between switches:

```
interface gigabitEthernet 1/1 switchport mode trunk switchport trunk allowed vlan 10,20,30
```

Ensure VLAN consistency across all connected switches .

Step 5: Configure Routed Ports (Optional)

For point-to-point links between Layer 3 devices, convert a Layer 2 port to a routed port:

```
interface gigabitEthernet 1/2 no switchport ip address 10.1.1.1 255.255.255.252 no shutdown
```

Routed ports create separate Layer 3 segments and are ideal for inter-switch or router connections .

Step 6: Configure Default Gateway and Routing

Set a default route for traffic leaving the switch:

```
ip route 0.0.0.0 0.0.0.0 192.168.30.254
```

For dynamic routing, enable protocols like OSPF or EIGRP on the SVIs or routed ports as needed .

Step 7: Verification

- Test inter-VLAN connectivity using ping between hosts in different VLANs.
- Verify SVI status with show ip interface brief.
- Confirm routing table entries with show ip route .

Best Practices for Dual-Core Switches

- Use redundant uplinks and configure ECMP for load balancing.
- Keep management VLAN separate from data and voice VLANs.

- Monitor CPU and memory usage to ensure dual-core resources are optimized.
 - Apply access control lists (ACLs) on SVIs or routed ports to segment traffic securely.
- By following these steps, a Layer 3 dual-core switch can efficiently handle inter-VLAN routing, point-to-point connections, and scalable enterprise traffic management.

Article Content

Configuring Layer 3 Interfaces

All Ethernet ports are switched interfaces by default. You can change this default behavior with the CLI setup script or through the

Related Video Reference

This video was associated with the source search result. Verify technical details against current product documentation and project requirements.

Contact Us

Continue your research online:

Website: <https://rivomultitrade.co.za>

Technical inquiry: <https://rivomultitrade.co.za/contact.html>

This document is for preliminary research. Verify specifications against current standards, product documentation and project requirements.

